

# Installation instruction do88 performance Intercooler BMW F20 F30 F87

Part number: ICM-280

This instruction shows how to replace the OEM intercooler with do88 performance intercooler kit.

At this type of installation we always recommend that you have mechanical experience and knowledge about safety during work on vehicles.

Parts included:

1. Performance intercooler
2. 2x Screws and 2x washers



1. Remove the plastic cover underneath the engine 21pcs Hex 8mm.



3. Disconnect both intercooler hoses. Push the hose towards the intercooler connection while loosening the metal clips. Then pull hose off.



2. Pry the plastic tabs free on both sides for the front intercooler air guide.

Then gently fold the air guide in front of the intercooler so the underside of the intercooler is free.



4. Remove 1x Torx T27 on each side of the intercooler then gently remove the intercooler from the car.

5. Now install the do88 Performance intercooler with the 2 Included screws. Reinstall all other parts in reverse order.

