



# Installation Instruction

Performance intake system

---



## SAAB NG 9-5 2.0T 2010-2011

This installation instruction is based on an install on a MY2010 SAAB 9-5 2,0T.  
Cars with other engines might differ a bit in some steps.



## Description

---

This instruction shows how to replace the OEM intake system with do88 performance intake system.

At this type of installation we always recommend that you have mechanical experience and knowledge about safety during work on vehicles.

## Parts List

---

- 1pc BMC performance air filter
- 1pc aluminum intake pipe
- 1pc silicone hose
- 1pc heat shield black
- 1pcs 70-90mm hose clamps
- 1pc 19-21mm hose clamp
- 2pcs M4x19mm torx screw
- 1pc plastic plug 13mm
- 140cm rubber sealing

**SAAB NG9-5**

Year models: 2010-2011

Engine: 2.0T, Turbo4, Turbo4 BioPower

The turbo inlet pipe is manufactured in 3" mandrel bent seamless aluminium pipe

Custom made high quality silicone hoses with 4 layers of polyester reinforcement

Always remember that the OEM turbo inlet pipe and hoses was designed for the p  
cause that the OEM pipe and hoses don't have the performance you need. So onl

do88 3" turbo inlet pipe comes with all hardware necessary for installation.

[Click here for installation guide!](#)

When you order this kit, there is one choice that has to be made:

**Color:**

Three different hose colors are available Blue / Black / Red.

**OEM reference:**

5556000



## Step 1

See instructions for IR-150 on

[www.do88.se/en/artiklar/saab-9-5-20t-2010-2011-inlet-pipe.html](http://www.do88.se/en/artiklar/saab-9-5-20t-2010-2011-inlet-pipe.html)

And scroll down and use the "Click here for installation guide!" and follow STEP 1-3.

## Step 2

Loosen 3x hose clamps.

Disconnect the cable connector on the AMM.

## Step 3

Remove 2x cable clips on the air filter box.

Lift the air filter box out from the car.



## Step 4

Remove 2x T20 screws and install the sensor from OEM AMM and install on the do88 aluminum pipe with included screws.



## Step 5

Remove the 15mm hex screw.



## Step 6

Install the included rubber sealing as shown on picture



## Step 7

Install the included 13mm plastic plug with the 19-21mm hose clamp.  
This step don't apply on 2.0t BIOPOWER.



## Step 8

Install the do88 Heat shield with the OEM 15mm hex screw.  
Don't tighten yet, see next step.



## Step 9

Install the aluminum pipe and install the filter.

Make sure the heat shield is installed correctly as shown on picture.

Tighten the 15mm hex screw.

Re-install all other parts in reverse order.



*Thank you for purchasing another do88 product.*

Please check our website frequently for new product releases.  
If you have any questions or concerns about this product please do not  
hesitate to contact us: [do88.se/contact](https://do88.se/contact)